MITEL

5201 IP Phone



NOTE: For more complete instructions on using the 5201 IP Phone, refer to the 5201 IP Phone - SX-200 ICP User Guide available at www.mitel.com or contact your Administrator.

Making an Internal Call

Quick Start Guide

- Lift the handset.
- **6** Dial the number.

Making an External Call

- **1** Lift the handset.
- **6** Dial the prefix for external calls (e.g. 9) and the number.

Placing a Call on Hold

- 5 Press Hold
- **1** Replace the handset.

Retrieving a Call from Hold

- **1** Lift the handset.
- 5 Press Hold

Leaving a Message

- 4 If the Message Indicator is lit,
- **1** Lift the handset and
- **5** Press Message, or if a voice mail system answers, record a message.

Retrieving a Message

4 If the Message Indicator is flashing,

520

- Lift the handset and
- **5** Press Message to automatically call your voice mail system or the last person who called you (who left the message).

Transferring a Call

- **5** While on a call, press **Trans/Conf**. You will hear dial tone.
- **6** Dial the number of the third party.
- **1** Hang up, or announce the transfer and hang up.

Conferencing Calls

- **5** While on a call, press **Trans/Conf**. You will hear dial tone
- **6** Dial the number of the third party. Wait for an answer.

5 Press Trans/Conf

M Mitel (design) is a registered trademark of Mitel Networks Corporation. © 2004, Mitel Networks Corporation. All other products and services are the trademarks of their respective holders. All rights reserved.

MITEL